


# Communicators



i-GSM02



i-SD01



i-DIG02

i-SD02



## Multi-function, plug-on communicators for the i-on and Menvier range.

Providing ARC reporting and SMS over standard PSTN or GSM. ARC reporting supports multiple formats including; fast format, contactID, SIA levels 1, 2 and 3. SMS provides up to four contacts with a variety of status messages.

The i-SD01, i-SD02 and i-GSM02 speech diallers allow personalised voice messages to be transmitted to up to four recipients.

## At a glance...

- i-GSM02 provides speech messages via GSM
- i-SD01 and i-SD02 provides speech messages via PSTN
- i-DIG02 uses SMS only
- i-SD01 compatible with the i-on16 only

## Variants

| Part No        | Description                                                       |
|----------------|-------------------------------------------------------------------|
| <b>i-SD01</b>  | Plug-on digital communicator by recorded message and SMS via PSTN |
| <b>i-GSM02</b> | Plug-on digital communicator by recorded message and SMS via GSM  |
| <b>i-SD02</b>  | Plug-on digital communicator by recorded message and SMS via PSTN |
| <b>i-DIG02</b> | Plug-on digital communicator by SMS via PSTN                      |

## Compatibility

|                   | Description                                                                      |
|-------------------|----------------------------------------------------------------------------------|
| <b>i-on16</b>     | 16 zone control panel (i-SD01 only, not compatible with any other control panel) |
| <b>i-on30EX</b>   | 30 zone control panel                                                            |
| <b>i-on40</b>     | 40 zone control panel                                                            |
| <b>i-on50EX</b>   | 50 zone control panel                                                            |
| <b>i-on160EX</b>  | 160 zone control panel                                                           |
| <b>Menvier30</b>  | 30 zone control panel                                                            |
| <b>Menvier40</b>  | 40 zone control panel                                                            |
| <b>Menvier100</b> | 100 zone control panel                                                           |
| <b>Menvier300</b> | 300 zone control panel                                                           |
| <b>Multibus</b>   | 1000 zone control panel                                                          |

## Technical specification

|                                 | <b>i-SD01</b> | <b>i-DIG02</b> | <b>i-SD02</b> | <b>i-GSM02</b> |
|---------------------------------|---------------|----------------|---------------|----------------|
| <b>Number of messages</b>       | 4             | 4              | 4             | 4              |
| <b>Number of contacts</b>       | 4             | 4              | 4             | 4              |
| <b>Speech and SMS over PSTN</b> | Yes           | No             | Yes           | No             |
| <b>Speech and SMS over GSM</b>  | No            | No             | No            | Yes            |
| <b>Downloader modem</b>         | No            | Yes            | Yes           | Yes            |
| <b>ADSL01 connections</b>       | Yes           | Yes            | Yes           | No             |